



17/11/15 11:12

Safety instructions

In order to ensure your safety and the safety of others, please make sure to read all the safety information before using this product. Keep this information in a safe place for future references.

Precautions

We recommend reading the following points:

- Create a back up periodically on other storage devices. Energy Sistem[®] shall not be liable for any damage or loss of data.
- Do not place the eReader near devices with strong magnetic fields. It may cause damage or loss of data.
- Do not disassemble nor remodel the device.
- Do not subject the device to shock nor let it fall to the ground.
- Do not use the eReader in a humid environment nor if it is wet.
- Do not put pressure on the eReaders display.
- Do not remove the microSD card nor turn it off while reading or during data writing in order to prevent loss of data.
- Make sure to unlock the microSD card before writing or deleting data.

Main features

- eReader with 6" E-Ink display, 16 greyscale levels and high contrast with selectable backlight. 600 x 800p resolution / 167ppi.
- Stylish and lightweight design. Only 8.1mm and 160gr.
- Opens books in no time, ultra-fast page turning and screen refresh.
- Anti-glare system to read comfortably under all lighting conditions and from different viewing angles.
- Rechargeable lithium battery. Lasts up to two months with a single charge.*
- Advanced reading functions: Screenlight function, different font types and sizes, bookmarks, landscape mode, favourite books, automatic page turning, automatic shutdown, go to page function.
- Supports Adobe[®] DRM (Digital Rights Management) for PDF and EPUB formats.
- User-friendly and multilingual user interface.
- Internal memory: 8GB, expandable up to 64GB via microSD/SDHC cards.
- Includes 1,500 works of universal literature.

*Based on half an hour of daily reading.

General overview



(<https://camo.githubusercontent.com>

/aa0786b58ef5af0c3899392cff0lc78e92le3acf

/687474703a2f2f7374617469632e656e6572677973697374656d2e636f6d2f696d616765732f6d616e75616c732f34323136392f353462666337663

1. Font size / page refresh (press and hold).
2. Screenlight ON / OFF / Level (press and hold).
3. Directional button
4. Select button
5. Options menu
6. Go back / Home
7. Micro USB port
8. MicroSD slot
9. ON/OFF button

Product content

1 x Energy eReader Screenlight

1 x MicroUSB cable

1 x Quick Guide

17/11/15 11:12

turn the device off.

Home screen



(<https://camo.githubusercontent.com/96f2e29ee88d53eed605d7a9bf8ad11907b08019>

/687474703a2f2f7374617469632e656e657267797374656d2e636f6d2f696d616765732f6d616e75616c732f34323136392f353462666336666

1. Recently read section. Features a progress bar.
2. Recently added section: Displays recently added books to the library.
3. Main icons.
4. Battery: Displays the eReader's battery level.
5. Date and time.

Main functions

Books

Displays all the books stored in the internal memory or microSD card.

Different visualization and book management options are available. These options are available through the options

menu  (<https://camo.githubusercontent.com/dc2338d062044e8e0fdbff777be35ebd80521cef>

/687474703a2f2f7374617469632e656e657267797374656d2e636f6d2f696d616765732f6d616e75616c732f34323136392f353462666336666

Options:

- Favourite books: Will only display books previously marked as favourites.
- Search: Search for a specific book.
- Sort by book title: Will display all books sorted in alphabetical order by their title.
- Sort by author: Will display books by author.
- Recently read: Will display recently read books.
- Recently added: Will display recently added books to the eReader.
- Show list: Will display all books in list format.
- Show cover: Will display book covers including their title.

It is also possible to search for a specific book entering its title after pressing 

(<https://camo.githubusercontent.com/9ba42e4fd9a6a5ca60973158d6e62806a2bfa383>

/687474703a2f2f73746f7469632e656e6572677973697374656d2e636f6d2f696d616765732f6d616e75616c732f34323136392f353462666530393

Advanced reading functions

There also are various options that can be set in order to make the reading experience more comfortable. These options are:

- Add bookmark: Adds a bookmark to the page you are reading. This way you will be able to continue reading easily.
- Bookmark: Displays all created bookmarks in the book.
- Index: Access the book index (if available).
- Go to page: Go to a specific page.
- Search: Search one or multiple words in a book.
- Font size: Choose one of six different font sizes.
- Font type: Choose the desired font type.
- Line spacing: Choose the desired line spacing.
- Margin: Choose the desired margin.
- Turn screen: Turn the display 90° to the right/left.
- Auto flip: With this function, your eReader will be able to turn pages automatically after a period of time.
- Page refresh: This function allows you to refresh every single page, every three or five pages.
- Add to favourites: Adds the book you are reading to your favourite books list.
- About the book: Shows information regarding the book you are reading (title, author, publisher, format).

Note: Not all eBook formats are compatible with these functions.

Images

Shows all image files stored in the device's internal memory or in the microSD card.

Once you access the image menu, you can choose to view the files as a list or as a thumbnail preview by pressing

 (<https://camo.githubusercontent.com/dc2338d062044e8e0fdbff777be35ebd8052lcef>

/687474703a2f2f73746f7469632e656e6572677973697374656d2e636f6d2f696d616765732f6d616e75616c732f34323136392f353462666530393

Press  (<https://camo.githubusercontent.com/dc2338d062044e8e0fdbff777be35ebd8052lcef>

/687474703a2f2f73746f7469632e656e6572677973697374656d2e636f6d2f696d616765732f6d616e75616c732f34323136392f353462666530393

after opening an image and a pull-down menu with the following options will appear:

- Turn left / right 90°
- Zoom in / zoom out
- Create a slide show using all stored images.
- Image information: Displays image information (name, size, file type).

Files

Shows all folders and files stored in the device's internal memory or in the microSD card.

Press (<https://camo.githubusercontent.com/dc2338d062044e8e0fdbff777be35ebd80521cef>)

/687474703a2f2f7374617469632e656e6572677973697374656d2e636f6d2f696d616765732f6d616e75616c732f34323136392f3534626665306131

to search a specific file by entering its name, to delete files/folders or select whether you want to browse the internal memory or microSD card.

Settings

In this menu you will find the following sections:

- **Bookmarks:** Displays all bookmarks (sorted by books) you have placed. This way you will be able to continue reading easily.
- **Power settings:** Set the time to enter stand by and auto power-off mode.
- **eReader information:** Displays the software version, the used and available storage space.
- **Language:** Select one of the 13 available languages.
- **Date and time.**
- **Restore default settings:** The eReader will erase all custom settings and return to default settings (bookmarks, favourite books, etc. will be removed).

Search

Quickly find the file or files you are looking for. Enter the name of the file you are looking for and press OK. The device will display all matching files.

Update

You can update your Energy eReader using your computer. The procedure is simple but must be done carefully and only if necessary.

Follow these steps to proceed with the update:

- Make sure your Energy eReader's battery is fully charged. Otherwise, connect your Energy eReader to an external power supply using a USB charger (5V / 1Ah max.) or to your computer via USB and wait until the battery is fully charged.
- Visit www.energysystem.com (<http://www.energysystem.com>) using your computer.
- Go to the "support" section and select "eReader".
- Choose your Energy eReader model from the drop-down list and download the latest firmware version.

***Important:**

- Make sure the version you are downloading is specific to your eReader model and serial number. Otherwise it could damage the device.
- Unzip the file on your computer.
- Open the included text file and follow the instructions to install the new operating system on your Energy eReader.

Troubleshooting

Is it possible to turn off the eReader without having an image on its screen?

The eReader will always have an image on its screen, but do not worry as it will not consume your eReaders battery. In addition to that, you can set another image to be displayed on the shut down screen.

I cannot change the font type of a pdf file

The pdf file is shown as created, with its own font types and sizes. Therefore you will not be able to commit any changes. This is the limitation you will have with this file format. However, you will be able to zoom in/out and browse through the book as if it was another format.

I cannot open an eBook

Check that your eReaders supports the eBook format.

The eReader is locked and does not respond.

Try pressing the reset button using a very thin object such as a paper clip. Then press the ON button.

The eReader does not show correctly the eBook characters, the space lining, etc..

This is due to the format the file has been digitalized in. Many eBooks are digitalized and formatted automatically without being reviewed. Use only reliable and quality content providers for the best reading experience.

Warranty conditions

Energy Sistem Soyntec S.A. is liable for any lack of conformity which exists at the time the goods were purchased during a period of 36 months. Batteries are excluded from the 36-month warranty, having a warranty period of 12 months.

This warranty covers any defects in workmanship or materials. This warranty does not cover any failure of the product due to accidents, misuse or alteration made by an unauthorized person.

The special 36-months warranty is valid for the European Union. For other countries, please refer to your specific legislation.

Support and warranty procedure

Visit the support section at <http://support.energysistem.com/es/support> (<http://support.energysistem.com/es/support>) and select your product to view the FAQ (Frequently Asked Questions), user manuals, drivers and updates available, as the possibility to submit a query to the Technical Service or consult the warranty.

Alternatively, you may prefer to contact the distributor from which you purchased the product, presenting the purchase receipt or invoice.

Specifications are subject to change without notice.

Trademarks. All company, brand and product names are trademarks or registered trademarks of their respective companies.

© 2014 by Energy Sistem Soyntec S.A. All rights reserved.

Declaration of conformity

Manufacturer name: Energy Sistem Soyntec S.A.

Date: 06/10/2014

Address: Pol. Ind. Finestrat - C/.Calpe, 1 - 03509, Finestrat, Alicante (España)

Tel: 902 388 388

Fax: 902 119 034

NIF: A53107488

We declare under our own exclusive responsibility that the product:

Energy SistemÂ™ - Energy eReader Screenlight

Manufacturing Country: China

Is in compliance with the essential norms and standards of the Directive 2004/08/CE of the European Parliament and of the Council of December 15th 2004.